SPARE PARTS LIST:



Spare part list

SCREF	1	pipe fitting G 1/4	SCREF	31	PVD coated needle
SCREF	2	PVD coated nozzle	SCREF	32	gun casing
SCREF	3	nut for head	SCREF	33	gasket screw cap
SCREF	5	gasket screw cap	SCREF	34	washer
SCREF	7	air regulation screw	SCREF	35	air feeding valve
SCREF	8	air regulation valve	SCREF	36	piston
SCREF	14	support block	SCREF	37	seeger
SCREF	15	release pivot handwell	SCREF	38	gasket
SCREF	19	cap spring container	SCREF	39	O-ring gasket
SCREF	21	washer	SCREF	40	stainless steel piston spring
SCREF	22	stainless steel spring	SCREF	B	O-ring gasket
SCREF	23	washer	SCREF	G	gasket
SCREF	24	stainless steel needle spring	SCREF	H	gasket
SCREF	27	spring container	SCREF	H/2	PTFE special gasket
SCREF	28	cylinder cap	SCREF	I	gasket
SCREF	29	regulation handwell	SCREF	L	O-ring gasket
SCREF	29/C	complete regulation handwell	SCREF	N	O-ring gasket
SCREF	30	head	SCREF	O	O-ring gasket